

Parts Manual

Hoyer® HML 400

Hoyer®

HML 400

NO	PART NUMBER	DESCRIPTION
Handles/Grips:		
1	222-6010	KIT, GRIPS (SET OF 4),HME
2	500-7103	GRIP, VINYL (BLACK)
Cradle:		
3	222-6003	KIT, CRADLE, COMPLETE, HME
4	222-6004	KIT, HDWR, CRADLE, HME
Leg Spreader:		
5	222-6011	KIT, SPREADER ASSY, HME
6	222-6008	KIT, SPRDR HNDL, HME
Actuator:		
N/S	222-6002	KIT, HDWR,J ACK/BOOM, HME
7	C-HLA-J	KIT,J ACK ASSY, C-HLA
Boom:		
8	222-6001	KIT, BOOM & HDWR, HME
Casters:		
9	222-6007	KIT, 4 IN CASTER (3X W/O BRAKE, 1X W/BRAKE, HARDWARE)
Scale:		
N/S	59011A	SCALE, DIGITAL, CRANK/HYD.
Upgrade Kit:		
N/S	200-6001	KIT, ACTUATOR, LINAK, HML400



